


12/24V POWER DISTRIBUTION PANEL



DESCRIPTION

The Somfy Power Distribution Panel is used to distribute 12 or 24V DC power to up to 10 Somfy low voltage motors. The panel includes mounting snaptrack and mating motor connectors. Typically the panel and power supply is installed in an electrical cabinet supplied by others.



Part No.: 1870122

WIRING DIAGRAM



12/24V POWER DISTRIBUTION PANEL

OPERATION

- A** Upon applying power to the panel, all 10 LED's should illuminate.
- B** Connect one motor to the panel and program per the instructions that accompany the motor.
- C** Repeat this process for every motor thereafter

TROUBLE SHOOTING

- If no LED's illuminate, check polarity input of the power supply and that power supply has AC voltage applied.
- If one or more LED doesn't illuminate, replace the appropriate fuse.
- If the motor does not respond, reverse the leads on the motor connector.

ORDERING INFORMATION

Description	Part Number
Sonesse™ 30 Motor	1000460
12 Motor Power Supply	9014245 (requires 2 power panels)
6 Motor Power Supply	9011995
3 Motor Power Supply	9014245
Motor Connector	55000334
SnapTrack Rail	9012294

For a summary of complete specifications and accessories please consult the Sonesse™ 30 Data Book.

SOMFY SYSTEMS, INC.
North America Headquarters
47 Commerce Drive
Cranbury, NJ 08512
Phone: US: 1-800-22-SOMFY
NJ: (609) 395-1300
Fax: (609) 395-1776

FLORIDA
6100 Broken Sound Pkwy. N.W., Suite 14
Boca Raton, FL 33487
Phone: (877) 227-6639
Fax: (561) 995-7502

CALIFORNIA
15291 Barranca Parkway
Irvine, CA 92618-2201
Phone: (877) 727-6639
Fax: (949) 727-3775

SOMFY ULC
SOMFY Canada Division
6315 Shawson Drive, Unit #1
Mississauga, Ontario L5T1J2
Phone: CN: 1-800-66-SOMFY
CN: (905) 564-6446
Fax: (905) 564-6448

SOMFY MEXICO, S.A. DE C.V.
Temazcal 19-B, La Loma
Tlalnepantla, Edo de Mex.
Mexico 54130
Tel: +52 (55) 5390-5664
Fax: +52 (55) 5390-5530